



## COMPRESSION FITTING C

NOT TO SCALE

### INSTALLATION STEPS:

1. CUT PIPE SQUARE.
2. MAKE SURE PIPE IS ROUND, NOT FLATTENED. CLEAN OFF ANY DIRT SO THAT THE SURFACE IS SMOOTH.
3. INSERT PIPE THROUGH COMPRESSION NUT. POSITION SPLIT RING ON THE END OF PIPE WITH THE TAPERED END TOWARD THE COMPRESSION NUT.
4. SLIDE COMPRESSION NUT OVER SPLIT RING AND ALIGN IT WITH THE THREADS ON THE BODY.
5. INSERT PIPE INTO THE BODY OF FITTING UNTIL FIRMLY SEATED.
6. TIGHTEN COMPRESSION NUT SECURELY TO THE FITTING BODY.

PROJECT NO: 013-2602  
DRAWN BY: EJB  
DATE: 2/17/15

## SEWER SERVICE CONNECTION DETAILS



601 P Street, Suite 200  
P.O. Box 84608  
Lincoln, NE 68508  
TEL 402.474.6311  
FAX 402.474.5160

EXHIBIT

3